

## What Size do I Need?

1. Determine the proposed finished grade.
2. Order the PermEntry size to assure the top of the unit (not the door) is a minimum of 3" above the finished grade.

Footing to Grade	PE Size	Casting			Door Height
		Height	Length	Width	
35" – 41"	S	45"	45"	51 ½"	52"
52" – 58"	O	62"	60"	51 ½"	30"
59" – 66"	B	70"	66"	55 ½"	22"
67" – 74"	C	78"	74"	55 ½"	19 ½"
75" – 82"	D	86"	86"	55 ½"	22"
83" – 91"	E	95"	95"	58"	22"
92" – 99"	F	103"	104"	58"	22"

